

CONFIGURATION HANDBOOK

BGCL96



LOREME 12, rue des Potiers d'Etain Actipole BORNLY - B.P. 35014 - 57071 METZ CEDEX 3
Phone 03.87.76.32.51 - Telefax 03.87.76.32.52
Contact : Commercial@Loreme.fr - Technique@Loreme.fr
Download manual at : www.loreme.fr

DEVICE PRESENTATION	p3
USERINTERFACE.....	p3
1) Tare the measure	p4
2) Alarms threshold setup	p4
3) Front face configuration	p4
RS232 LINK SETTING	p5
TERMINAL MODE	p6
1) Visualization	p6
2) Configuration	p6
2.1) Method	p6
2.1.1) Menu selection.....	p6
2.1.2) Parameter selection	p6
2.1.3) Value acquisition	p6
2.1.4) Remarque	p6
2.2) Language.....	p6
2.3) Input	p7
2.4) Display range	p7
2.5) Analogs outputs	p7
2.6) Special functions	p8
2.7) Relays	p8
2.8) Communication.....	p9
2.9) Tag configuration	p10
OFFSET	p10
FIRMWARE UPLOAD	p11
EMC CONSIDERATION	p12
1) Introduction	p12
2) Recommendation of use	p12
2.1) General remarks	p12
2.2) Power Supply	p12
2.3) Inputs / Outputs	p12
WIRING	p13
PC - DEVICE LINK	p13
DIAGRAM OF CONNECTION	p13
RS485 MODBUS COMMUNICATION	p14
MODBUS TCP COMMUNICATION.....	p16
PROFIBUS COMMUNICATION	p17
CONNECTION TO COMMUNICATION NETWORK.....	p19

Device Presentation


The purpose of this configuration handbook is to allow to become familiar with the functions supplied by the device. The programmable bargraph BGCL96 allows with his circular ramp and the display, to evaluate easily the state of his process inputs.

It's necessary to notice the difference between different models:

- BGCL96:** universal input, more than 10 types.
- BGCL96/S:** 1 insulated analog outputs.
- BGCL96/R1:** 1 relay.
- BGCL96/R2:** 2 relays.
- BGCL96/R3:** 3 relays.
- BGCL96/R4:** 4 relays.
- BGCL96/C:** 1 RS485 Modbus or Profibus link.
- BGCL96/CMTCP:** 1 Ethernet Modbus TCP link.

The technical data sheet is downloadable here: http://www.loreme.fr/fichtech/BGCL96_eng.pdf

USER INTERFACE



The device front panel includes:

- One 4 digits dot matrix display, 10 000 points resolution,
- One 55 LED circular ramp for input measure,
- Four signaling LED:
 - R1 alarm 1 signaling,
 - R2 alarm 2 signaling,
 - R3 alarm 3 signaling,
 - R4 alarm 4 signaling,
- a 3,5mm jack socket for RS232 link,
- 3 Push-buttons:
 - ✓ **(Config.)** Enter in configuration mode.
 - ▲ **(Tare)** Measure tare access or <YES> button or increment button.
 - ▼ **(Rel.)** Alarm threshold setup access or <NO> button or decrement button.

In normal operation, the device displays the input measure on the circular ramp and the 4 digits display. In case of an internal default or sensor breaking, the message 'Err' is displayed on the 4 digits display and the ramp flashes.

1) Tare the measure

The ▲ <Tare> button permits to access the measure tare menu. The message « TARE Y/N? » scrolls on the display. The ▲ <yes> button activates the tare and the ▼ <no> button deactivates it. After activation, zero is displayed.

Note:

The tarred measure is saved in non-volatile memory and remains active after power Off.

2) Alarms threshold setup

The access to alarms threshold setup with the push-buttons is function of the alarms configuration. It is necessary that the alarm is active (see threshold configuration p8).

Adjustment process:

- push the ▼ <Rel.> button to access the setup. The message 'ADJUST THRESHOLD x?' is displayed and the led Rx is on. To access the relay x threshold setup procedure, press the ▲ button or press the ▼ button to switch to the next threshold (If it was the last threshold, the device returns in measure mode).
- After pressing the ▲ button, the alarm threshold is displayed.
- if the adjustment is authorized (local configuration with the terminal), the threshold is adjustable with the ▲ , ▼ buttons, otherwise, it is only displayed. The adjustment speed is function of the time the increment or decrement button is pressed.
- the threshold adjustment is memorized by pushing the ✓ (Config) button.
- if no button is pushed during a delay of 30 seconds, the device returns in measure mode without saving the adjusted threshold.

3) Front face configuration

It is possible to configure the device with the three button in the front panel.

Parameters that can be modified are:

- The language,
- The input type and scales,
- The display range: low scale, high scale, decimal number.
- The display filter: The display filter is adjustable from 1 seconds to 60 seconds.
- The output: output type, low scale, high scale, security value, response time.
- The relays: breaking/watchdog detection, threshold detection, threshold type, threshold value, hysteresis, security type, activation delay and deactivation delay.
- The communication: For MODBUS/PROFIBUS, address, speed, parity and for MODBUS/TCP, the IP address.
- square root function: YES or NO.

Access to the configuration mode is done by pressing the ✓ (Config) button. If the configuration is locked, the message '**NOT ALLOWED!**' is displayed. Lock/Unlock of the configuration access is only possible via the RS232 link terminal mode.

For each step a message scrolls on the display. The ▲ (YES) activates the function or provides access to the parameter setting. The ▼ (NO) disables the function or skips to the next rubric.

Setting a value is made with the ▲ , ▼ buttons. All parameters are limited except the display range scale. (the message LOW or HIGH is display in overflow case). Use the ✓ (Config) button to validate the value.

The message OK ! is displayed at the end of the configuration and all the parameters are memorized.

Note:

If no button is pushed during a delay of 30 seconds, the device returns in measure mode without saving the configured parameters.

RS232 link setting

The device can be configured or updated in terminal mode via an RS232 link.

Step 1: Driver installation for USB / RS232 adapter



- download driver at www.loreme.fr:
http://www.loreme.fr/aff_produits.asp?rubid=53&langue=fr
 - Click on executable file to install the driver,
 - Plug the cable on a USB port, Windows install a new serial communication port **COMx** (x >= 4).
- Note :**
The use of the cable on another USB port don't generates a new communication port. Use of another adapter generates another communication port number (COMx) and requires the reconfiguration of the HyperTerminal.

Step 2: Setting of terminal emulation software (PC with Windows).

1 The terminal emulation software for PC « HyperTerminal » is resident in windows up to XP version. For later versions, it is downloadable on : www.loreme.fr in **download part** (<http://www.loreme.fr/HyperTerm/htpe63.exe>)
=> Run the downloaded software to install it.

2 Start a "hyper Terminal" connection :
- Click on "**START**" button
Up to XP version
- Go to "**Programs \ Accessories \ Communication \ Hyper Terminal**"
- Click on "**Hypertrm.exe**"
Or if the software was downloaded
- Go to "**All programs \ HyperTerminal Private Edition**"
- Click on "**HyperTerminal Private Edition**"

3 Enter name for the new connection


4 Choose the communication port related to the adapter.

5

Choose:
- 9600 bauds
- 8 DATA bits
- no parity
- 1 stop bit
- **XON/XOFF**

6 The PC is now in terminal mode, connect it to the device by plugging the RS232 cable. The measure is now displayed on the terminal. To access configuration, press 'C' key.

7 When leaving Hyper terminal, the following window will appear. By saving, the terminal session will start with the same configuration.

Thus, the shortcut  **LOREME.ht** will permit to communicate with all LOREME devices.

Note: to modify the parameters of terminal mode whereas this one is already started, it is necessary, after having carried out the modifications, to close the terminal and to open it again so that the modifications are effective.

1) Visualization

After Power on, the device is automatically put in measure mode.

2 information's are available on screen:

10.00 mV	Input measure value
11.9 mA	Output result value (only if /S option).

2) Configuration

This manual resume in detail the different configuration possibilities:

Languages, input, display range, display filter, output (/S), relay 1, 2, 3, 4 (/Rx), communication (/C, /CMTCP), special functions, tag.

To enter the configuration mode, type the "**C**" key. the message '**CONF**' is displayed.

2.1) Method

At the configuration time, the user is asked different types of questions. For each one, several answers are possible. You will find below the detailed description of each case.

2.1.1) Menu selection

example: INPUT The user makes a choice by pressing the keys "**Y**" or "**N**".
(Y-N) This choice allows to access the different menus of configuration.

2.1.2) Parameter selection

example: VOLTAGE or VOLTAGE
(Y-N) YES (Y-N) NO

Previous choice = YES: - pressing "**Y**" or "**Enter**" => choice validation = YES,
- pressing "**N**" => choice changing = NO with validation.

Previous choice = NO: - pressing "**N**" or "**Enter**" => choice validation = NO,
- pressing "**Y**" => choice changing = YES with validation.

2.1.3) Value acquisition

example: LOW SCALE
4 mA

Two cases are possible:

- validation without modification, just press "**Enter**",
- value modification on keyboard (simultaneous display), followed by validation with "**Enter**".

It is possible, when a mistake is made during a value acquisition, before validating it, to go back by pressing the backspace key. which re-displays the message without taking notice of the wrong value.

Note:

- In configuration mode, if there is no action, device goes back in operating mode after a two minutes delay without taking notice of modifications made before.
- In configuration mode, if you want to go back to measure mode without taking notice of the modifications made before, you just have to press "ESC".

2.2) Language

Languages possibilities are:

- French,
- English.

2.3) Input

The input possibilities are:

- Voltage (mV, mV differential, V)
- Current (mA)
- Resistance (Ω)
- Frequency (Hz), duty cycle (%)
- Thermocouple ($^{\circ}\text{C}$) internal or external compensation, linearized or not.
- Pt 100 ($^{\circ}\text{C}$) 3 wires, linearized or not.
- Pt 100 ($^{\circ}\text{C}$) 4 wires, linearized or not

with for each input type, the choice of low scale, high scale and display range.

Particularities:

- Thermocouple:

Choice of thermocouple type, B, E, J, K, R, S, T, N, W3, W5 (another on request).

Choice of compensation type, internal or external.

Choose **internal compensation** when thermocouple is extended up to device with a compensation cable.

Choose **external compensation** when thermocouple is not extended up to device with a compensation cable, but up to a compensation box where temperature will be known and stabilized. This is the value of temperature that will be typed as the external compensation value (except thermocouple type B).

- Potentiometer:

Configure voltage input (V):

- low scale: 0 V
- high scale: 5 V

Move potentiometer at the start and at the end of range, notice each value.

Change voltage input (V):

- low scale = start range value,
- high scale = end range value.

See wiring diagram for potentiometer wiring.

- Sensor power supply:

To supply a loop powered converter and measure the loop current, it's necessary to configure the device in 4-20 mA current input. See wiring diagram for sensor power supply and current input wiring.

2.4) Display range and filter

The range interpret the input signal in a physical size, thus making the reading of the measured information easier.

Ex: Input 4-20 mA / Range 0-1000 kg
 → Input = 12 mA, indication = 500 kg

To configure the range, it is necessary to configure:

- the unit
- the low scale
- the high scale
- the decimal number
- the display filter

The unit of the display range is facultative and is only useful to interpret the real size on the terminal. It is limited to 4 characters.

The decimal number correspond to the number of digit displayed behind the decimal point. This number is limited to 3.

The display filter allows to reduce display instability when measured value is disturbed. It is adjustable from 1 to 60 s.

2.5) Analog output

The device can, by the /S option, provide an analog output, insulated and configurable. Analog output configuration is presented through 2 rubrics:

- Output type:

- current output (mA),

- voltage output (V).

And for each output type, the low and high scale.

- Output parameters:
 - security value,
 - limitation,
 - response time.

The security value allows to set the output on a known state when there is a sensor breaking or a measure range overflow. This value will be transferred to output.

The limitation allows to bound the output signal swing to the configured output scales for all input signal values. Only security value goes beyond this function.

The response time is adjustable from 0 to 60 s.

2.6) Specials functions

The device disposes of some special functions to adapt its operation.


The **front face configuration lock** allows the user to lock the configuration procedure accessible via the front face buttons.

The **square root** function executes a square root on the input range percentage. The result is reported on analog output and on the displayed value.

The **special linearization** function allows the user to create a personalized response curve by configure points of correspondence between measured input signal and the display range. When this function is choose, it is directly activated, but linearization points are not modified. To modify linearization points, it is necessary to validate by YES the configuration question.

When **special linearization** is enabled, the device uses linearization curve corresponding to configure points (2).

To personalize a response curve (2), it's necessary to set for each curve point the input value and the corresponding display range value (maximum 26 points including input points 0 % and 100 %). So, for each measured point, the device will make correspondence to the linearized display range value.



2.7) Relays

The device can, by /R1, /R2, /R3 or /R4 option, provide respectively 1, 2, 3 or 4 independently configurable alarm relays. Relays configuration is presented through 2 rubrics:

- Detection type:
 - breaking detection/watchdog function,
 - threshold detection.

The breaking/watchdog detection activates alarm on sensor breaking and on internal failure.

The threshold detection activates alarm on threshold overstepping. It is necessary to choose threshold type, high or low, threshold and hysteresis value. The two detections types can be activated simultaneously.

The **threshold detection** works in this manner:

- **high threshold** detection:
 - .alarm is activated when measure goes above threshold,
 - .alarm is removed when measure goes below threshold minus hysteresis.
- **low threshold** detection:
 - .alarm is activated when measure goes below threshold,
 - .alarm is removed when measure goes above threshold plus hysteresis.

Note: The hysteresis value is relative to the display range scale and can be configured between 0 % and 99 %.


- Relay parameter:
 - adjustable,
 - security,
 - delay.

When alarm is used in threshold detection, it is possible to access the **threshold adjustment** in front face with the push-buttons. This possibility can be deactivated if the adjustment must be inaccessible in front face, only the visualization is then possible.

Each relay can be set in **positive security** or **negative security**. This function allows to choose between the activation or the de-activation of the relay when alarm is activated:

- in **positive** security, relay is switched when alarm is active, "works" contact is closed on alarm, opened out of alarm, "back" contact is opened on alarm, closed out of alarm.
- in **negative** security, relay is switched when alarm is inactive, "works" contact is opened on alarm, closed out of alarm, "back" contact is closed on alarm, opened out of alarm.

The delay value, configurable from 0 to 14400 s (4 hour), determines the time above which alarm changes its state after event appearance and disappearance. The device provide for each relay a configurable delay when alarm is activated and when alarm is removed.



2.8) Communication

This part of configuration is accessible only on a device with the option /C or /CMTCP.

2.8.1) MODBUS TCP

The parameters are the IP address and the network mask. The entry is made in 3digits, the character separation '.' is display automatically.

Note: When using the buttons in front panel, only the IP address can be modify.

2.8.2) MODBUS

The communication parameters are:

- Network Address of the device (1 to 255),
- baud rate : 1200, 2400, 4800, 9600,19200, 38400 bauds,
- parity: odd, even, none.

The data are present in several format:

- floating 32 bits IEEE format,
- 16 bits unsigned integer (percentage of the measurement range),
- 32 bits reversed signed integer (value x 100).

2.8.3) PROFIBUS

The communication parameters are:

- Network Address of the device (1 to 126)
- baud rate : 9600, 19200, 93.75K, 187.5K, 0.5M, 1.5Mbauds

The data exchange are : measure value in float 32bits IEEE, state of alarm 1 and 2, input state.

2.9) Tag configuration

The tag allows to easily identify the converter. It can be made of up to 10 alphanumerical characters. The user only have to enter the tag on the keyboard and validate it with the "Return" key. The tag will now be displayed on each configuration access.

OFFSET

Sometimes, it may be interesting to modify the measure by a simple terminal keyboard intervention. It can be used in many situations as sensor aging, an input refinement as a result of magnifying effect...

To shift the measure, it is necessary:

- to be in measure mode,
- type on "+" or "-" to access the function,
- on terminal the display become:

100.5 DC	measure value with offset,
OFFSET 10	offset function, offset value.
- use keys "+" and "-" to adjust offset, measure is directly modified.
- type on "ENTER" to memorize offset.

When the device is not supplied or is in configuration mode, offset stay active. To reset offset, it is necessary to start "OFFSET" function, put this value to zero with the "+" and "-" keys, then validate by "ENTER". In offset control mode, when there is no action on "+", "-" or "ENTER" keys during 20 s, the device leave the mode without keeping the adjusted offset.

Attention, the offset has no effect on the measure when the converter is in frequency or duty cycle mode !!!

Firmware update

To access to the firmware update function, you must first open an HyperTerminal session on a PC, connect the device to the PC with the RS232 link cable and then power on the device.

The following character is send to the terminal:

> <————— The device sends this character then it waits the « F » key during 0.5 s.

If the user has pressed the « F » key in the allowed time, the following message is displayed in the HyperTerminal windows:

```
FIRMWARE LOADER Rev3
READY TO TRANSFER...
```

The device is now in file waiting mode, This file is provided by LOREME. This file contain the firmware code in intel HEX format. Selected the « Transfer », « Send a text file... » in the HyperTerminal menu
Select the directory and the file, click on « OPEN ». The HyperTerminal program begins to send the file to the device.

```
FIRMWARE LOADER Rev3
READY TO TRANSFER...
*****
```

The star characters appears to show the progress of the uploading.

At the end, the message « **PROGRAMMING OK !** » is display if no error occurs. If not, several messages are display:

- **SERIAL COM ERROR !** Error during receipt.
- **SERIAL TIMEOUT !** Waiting time of receipt elapsed.
- **PROGRAMMING FAILED !** Programming error in the internal flash memory..

Attention

*If an error occurs during the programming process, it is necessary to start again the whole procedure.
A bad programming leads to an inoperative device.*

EMC Consideration

1) Introduction

To meet its policy concerning EMC, based on the Community directives **2014/30/EU** & **2014/35/EU**, the LOREME company takes into account the standards relative to this directives from the very start of the conception of each product.

The set of tests performed on the devices, designed to work in an industrial environment, are made in accordance with **IEC 61000-6-4** and **IEC 61000-6-2** standards in order to establish the EU declaration of conformity. The devices being in certain typical configurations during the tests, it is impossible to guarantee the results in every possible configurations. To ensure optimum operation of each device, it would be judicious to comply with several recommendations of use.

2) Recommendations of use

2.1) General remarks

- Comply with the recommendations of assembly indicated in the technical data sheet (direction of assembly, spacing between the devices, ...).
- Comply with the recommendations of use indicated in the technical data sheet (temperature range, protection index).
- Avoid dust and excessive humidity, corrosive gas, considerable sources of heat.
- Avoid disturbed environments and disruptive phenomena or elements.
- If possible, group together the instrumentation devices in a zone separated from the power and relay circuits.
- Avoid the direct proximity with considerable power distance switches, contactors, relays, thyristor power groups, ...
- Do not get closer within fifty centimeters of a device with a transmitter (walkie-talkie) of a power of 5 W, because the latter can create a field with an intensity higher than 10 V/M for a distance fewer than 50 cm.

2.2) Power supply


- Comply with the features indicated in the technical sheet (power supply voltage, frequency, allowance of the values, stability, variations ...).
- It is better that the power supply should come from a system with section switches equipped with fuses for the instrumentation element and that the power supply line be the most direct possible from the section switch.
- Avoid using this power supply for the control of relays, of contactors, of electrogates, ...
- If the switching of thyristor statical groups, of engines, of speed variator, ... causes strong interferences on the power supply circuit, it would be necessary to put an insulation transformer especially intended for instrumentation linking the screen to earth.
- It is also important that the installation should have a good earth system and it is better that the voltage in relation to the neutral should not exceed 1V, and the resistance be inferior to 6 ohms.
- If the installation is near high frequency generators or installations of arc welding, it is better to put suitable section filters.

2.3) Inputs / Outputs


- In harsh conditions, it is advisable to use sheathed and twisted cables whose ground braid will be linked to the earth at a single point.
- It is advisable to separate the input / output lines from the power supply lines in order to avoid the coupling phenomena.
- It is also advisable to limit the lengths of data cables as much as possible.

Wirings

PC - DEVICE LINK



DIAGRAMS OF CONNECTIONS



- | | |
|------------------------|--|
| mV, Tc input: | terminal D (+), terminal F (-) |
| V/Frequency input: | terminal B (+), terminal F (-) |
| mA input: | terminal C (+), terminal F (-) |
| Potentiometer input: | terminal G (supply), terminal B (+), terminal F (-) |
| Strain gauge input : | terminal G (supply +), terminal F (supply -) |
| | terminal E (measure +), terminal D (measure -) |
| Sensor supply input: | terminal H (+), terminal F (-) |
| Resistance, | |
| Pt100 input (3-wires): | terminal D (+), terminal F (-), terminal E (line) |
| Pt100 input (4-wires): | terminal A (line +), terminal D (+), terminal F (-), terminal E (line -) |
| Analog output: | terminal Analog+, terminal Analog- |
| Relay 1,2,3,4: | terminal Rx (rest), terminal Tx (work), terminal Cx (common) |
| Power supply (AC/DC): | terminals L+, N- |

RS485 MODBUS communication

1) Feature

Protocol:	MODBUS RTU
Link:	RS485
Baudrate:	1200 to 38400 bds
Parity:	even, odd, none
Address:	1 to 255
Connector:	3 points spring connector
Reading request:	function code 03,04
Type of data:	electrical measurement.
data format:	Measure in 32 bits IEEE floating point, 32 bits signed integer format, 16 bits unsigned integer.

2) Data description

2.1) Available data

All measures are accessible in reading mode.

Data's are available in different formats:

- 2 words, 4 bytes, for the 32 bits IEEE floating point format,
- 1 word, 2 bytes, for the measure in 16 bits integer format. The value is in percent of the input scale,
- 2 words, 4 bytes, for the 32 bits signed integer format,

=> Consult the enclosed tables for data's detail.

2.2) Exception frame

If the slave receive an corrupted frame (CRC16 or parity), it doesn't answer. If it is a frame error (data address, function, value), the slave send a exception frame.

The exception frame is a 5 bytes long.

Details of the exception frame:

The function code of the exception frame is identical to the question frame, but this MSB bit is set to 1.

The error code indicate the reason of the exception frame


Error code	Details
\$01	Function code not allowed. Only the function code \$03 or \$04 are used by the BGCL96 (register reading function).
\$02	Data address not allowed
\$04	Slave busy. The internal communication slot is not in connection with the measure part.

2.3) Data format

- Data in 32 bits IEEE floating point format

Data are transmitted Most Significant Byte first, 4 bytes or 2 words long.

\$FFFFFFFF = sensor braking.



- Data in 16 bits integer format.

Data are transmitted most significant byte first, 2 bytes or 1 word long.


The 16 bits unsigned integer values correspond to the percentage of the input measure scale.

\$0000 ou \$FFFF = sensor breaking.

\$0001 = Low overstepping of input scale,

\$FFFE = High overstepping of input scale.

\$0002 à \$FFFD = Percentage of input scale.



Example:


- input PT100 (scale: -200 /800°C), 16 bits measure = 37442 => $(((37442 - 2)/65531) * (800+200)) - 200 = 371,3^{\circ}\text{C}$

- input Tc K (scale: -200 /1350°C), 16 bits measure = 20900 => $(((20900 - 2)/65531) * (1350+200)) - 200 = 294,3^{\circ}\text{C}$

- Data in 32 bits signed integer format.

Data are transmitted **Least significant word** first, 4 bytes or 2 words long.

The 32 bits signed integer value correspond to the measure x 100.



3) measure in 32 bits floating format

Address in decimal (Hexadecimal)	Designation
4096 (\$1000)	Measure in IEEE 32 bits floating point Word 1
4097 (\$1001)	Word 2

4) measure in 16 bits format

Address in decimal (Hexadecimal)	Designation
0000 (\$0000) or 12288 (\$3000)	Measure in 16 bits integer Percentage of input scale Word 1

5) measure in 32 bits format

40960 (\$A000)	Measure x100 in 32bits signed integer Word 1
40961 (\$A001)	Word 2

MODBUS TCP communication

1) Features

Protocol:	MODBUS TCP
Link:	Ethernet
Speed:	10/100 base T
Default IP address:	192.168.0.253
Connector:	RJ45
Reading operation:	Code function 03, 04
Writing operation:	Not allowed

2) Data description

The available data are the same as for the MODBUS communication (see pages 14/15).

3) Response time

It is the delay between a read request send by the master and the response frame send by the BGCL96/CMTCP.
The BGCL96 device answer in less of 30 ms to a read of 4 registers.

4) Use with more than one Modbus TCP master

The BGCL96/CMTCP supports to be access by masters with different IP address. However, the network load have to be less then 30 requests /second. A too high network load could lead to communication errors.

RS485 PROFIBUS communication

1) Features

This device meet the PROFIBUS specification EN 50710 volume 2
 Supported baud rate: 9.6K, 19.2K, 93.75K, 187.5K, 0.5M, 1.5Mbauds
 Type of transmission: RS485, 8bits data, 1 stop, even parity
 Connector: unpluggable 2 wires

2) Implementation

The network address and the baud rate should be configured in the device. All communication information's are in the GSD file provide with the device (or may be download from www.loreme.fr)

This information's are in 3 parts:

- Information about the functionality of the device,
- data configuration,
- list of alarms and parameters

2.1) Explanation of input/output data

A data exchange frame has 105 byte long:

- 96 bytes for the measure in 32bits IEEE floating point number
- 3 bytes for the alarm 1 status (1bit by channel, set to 1 if alarm activated)
- 3 bytes for the alarm 2 status (1bit by channel, set to 1 if alarm activated)
- 3 bytes for the input status (1bit by channel, set to 1 if input is breaking)

2.2) Explanation of diagnostic data

There are 6 byte of standard diagnostic data and 2 byte for device specific data.

2.3) Data exchange information:

Remark: Only the channel 1 is use by the BGCL96 and the alarms 1 and 2 are always 0.

								Total	
b7	b6	b5	b4	b3	b2	b1	b0	word	byte
Channel 1				byte 1	word 1			1	1
				byte 2					2
				byte 3	word 2			2	3
				byte 4					4
Channel 2				byte 1	word 1			3	5
				byte 2					6
				byte 3	word 2			4	7
				byte 4					8
Channel 3				byte 1	word 1			5	9
				byte 2					10
				byte 3	word 2			6	11
				byte 4					12
Channel 4				byte 1	word 1			7	13
				byte 2					14
				byte 3	word 2			8	15
				byte 4					16

		Words	bytes
AL1	Channel 24	byte 3	word 2
		byte 4	
Status	Channel 1 to 8	byte 1	
AL2	Channel 9 to 16	byte 2	
	Channel 17 to 24	byte 3	
Status	Channel 1 to 8	byte 1	
Sensor	Channel 9 to 16	byte 2	
	Channel 17 to 24	byte 3	
braking	Channel 1 to 8	byte 1	
Status	Channel 9 to 16	byte 2	
	Channel 17 to 24	byte 3	

2.4) Alarms and input Status byte

When a bit is set to 1, the corresponding channel is in alarm or input breaking

	b7	b6	b5	b4	b3	b2	b1	b0	bit
State of channel 1 to 8	8	7	6	5	4	3	2	1	byte 1
State of channel 9 to 16	16	15	14	13	12	11	10	9	byte 2
State of channel 17 to 24	24	23	22	21	20	19	18	17	byte 3

2.5) Device specific diagnostic data

byte 1 à 6 : standard bytes

0	0	0	0	0	0	1	0	byte 7: header byte 8: diagnostic bit0: measure default
0	0	0	0	0	0	0	0/1	
b7	b6	b5	b4	b3	b2	b1	b0	

The 'Measure Default' appears when the communication slot don't receive data from the measure part within a 3s delay. (It's the case if the user enter the device in configuration mode by RS232 link or front panel)


In this case ALL data exchanged are set to 0 !!

2.6) Data format for measure value (only channel 1)

- Date in IEEE 32 bits floating point number.


Data are transmitted Most significant byte first, 4 bytes long.

\$FFFFFFFF = sensor breaking.




Connection to the communication network


1) Connection to a MODBUS network



The terminal (3) is not connected



2) Connection to a PROFIBUS network



The terminal (3) is not connected

